

# INSTALLATION INSTRUCTIONS

smart<sup>TOP</sup> 986



Comfort roof control unit for Porsche Boxster (986)



Open driver's door. Locate the relay and fuse box in the upper left of the driver's foot well.



The module marked is the roof control unit. It has the size of two normal relays and is marked with either a black triangle or a quadrate on its front.



Remove the module by working it up and down a little while pulling, until it comes out.



Just plug in the smartTOP module instead and press firmly. Make sure it sits tight.  
\*DONE\*